


FITTING REPLACEMENT VERTICAL BLIND SLATS OR LOUVRES

1 FITTING THE LOUVRES


Unclip the damaged slat from the headrail and disconnect the chain link from the bottom edge

Using the plastic hook in the top of the replacement slat, place onto the headrail hook from where you removed the original slat. Repeat for all replacement slats, ensuring they are all facing the same direction.




2 FITTING THE WEIGHTS

Simply slide the weights into the pocket at the bottom of the replacement slat, making sure the lugs are at the top near the seam line.



3 FITTING THE CHAIN

To attach the chain to the weights, simply slide the clip down the lug of the weight. Do not push the clip onto the lug, this will only weaken the clip or cause it to snap completely.



4 OPERATING YOUR BLIND

Chain/Cord System

Use the operating chain at the side to gently rotate the louvres. Use the operating cord at the side to open and close the blind (only when the louvres are fully open).

Wand System

Twist the wand to rotate the louvres. Pull the wand across in either direction to open and close the blind.

P-Clip

The device must be installed at maximum distance possible from the control mechanism, and not less than 1.5m from the floor, to prevent the looped cord/chain from becoming slack.

1. Make sure the chain and cord are hanging loose where you want them to be secured.
2. Ensure the chain and cord are taut, the P-Clip is at the bottom of the loops and that the chain and cord are able to manoeuvre correctly.
3. Screw the P-Clip to a wall adjacent to the blind ensuring the chain & cord remain taut. The controls will be held permanently taut and under constant tension.



Assembly and installation of this product can be completed by non-professionals, in accordance with current trade and safety standards. Please consult a professional if any doubt exists.

Young children can be strangled by loops in pull cords, chains, tapes, and inner cords that operate the product. To avoid strangulation and entanglement, keep cords out of the reach of young children. Cords may become wrapped around a child's neck. Move beds, cots and furniture away from window covering cords. Do not tie cords together. Make sure cords do not twist and create a loop.